


REPAIR PARTS

GRASS CATCHER - MODEL NUMBER CE36A

18



REPAIR PARTS

GRASS CATCHER - MODEL NUMBER CE36A

KEY NO.	PART NO.	DESCRIPTION	KEY NO.	PART NO.	DESCRIPTION
1	7192J	Tie, Cable	23	132983	Spring, Cover R.H. (gray)
2	69180	Locknut #10-24	24	127720X	Post, Support
3	127533	Screen, Cover	25	63124	Locknut 5/16 x 18
4	126816	Cover	26	4939M	Spring, Retainer
5	128598	Chute, Upper	27	74760512	Bolt, Hex 5/16-18 x 3/4
6	18021008	Screw, Special	28	130889	Bracket, Mounting
7	130933	Indicator, Bagger Full	29	17490508	Screw, Thread Rolling 5/16-18 x 1/2
8	87175	Screw, #10-24 x 1-1/8	30	131137	Pin, Support Post
9	19061216	Washer 3/16 x 3/4 x 16 Ga.	31	134496	Cap, Tubing End
10	7206J	Spacer, Split	32	126919X	Bagger, Frame
11	60867	Nut, Acorn #10-24	33	128600	Pin, Hinge
12	10071000	Washer, lock	34	127534	Gasket, Cover
13	109808X	Latch, Chute	35	129585	Container, Top
14	2029J	Nut, Weld	36	129586	Container, Bottom
15	74930516	Bolt, Hex 5/16-18 x 1	37	132256	Seal, Cover
17	130758	Latch Assy., Bagger	38	131859	Latch Handle, Cover
18	131270	Chute, Lower	39	135495	Strip, Seal
19	133841	Nut, Acorn 5/16-18	40	71141008	Screw #10-24 x 1/2
20	71161010	Screw #10-24 x 5/8	41	73800600	Locknut 3/8-16
21	132796	Spring, Cover L.H. (black)	42	123659X	U-Bolt
22	133235	Spacer, Cover	43	123635X	Weight, Wheel
				104419X	Bag, 3.0 mil. 30 Gallon Trash (not included with bagger)
				132409	Owner's Manual (English)
				132471	Owner's Manual (French)