



Green Passion

Illustrated Parts List


XB41 - Model Year 2008

- Use GLOBAL GARDEN PRODUCT Genuine Spare Parts specified in the parts list for repair and/or replacement.
- The contents described in the parts list may change due to improvement.
- The drawings of the spare parts are only indicative and might not represent the part in question exactly.
- The indications "right" - "left" - "front" - "rear" refer to the position of the operator when using the machine.
- When placing orders of parts for repair and/or replacement, make sure that the illustrated parts list is the one applying to the machine's year of manufacture, as shown on the identification plate attached to the machine.

COPYRIGHT by GLOBAL GARDEN PRODUCTS

All rights reserved. No part of this material may be reproduced or transmitted, in any form or by any means, electronic or mechanical, including photocopying, recording or by any information storage and retrieval system, without permission in writing from GLOBAL GARDEN PRODUCTS.

Engine 1






XB41 - Model Year 2008



Engine 1

Pos.	Part no.	Q.ty	Description	Remarks
1	2135040	12	Screw	
2	4540800	1	Trasm. Support Case	
3	2432030	2	Nut	
4	2132500	1	Screw	
5	2312120	1	Washer	
5a	3211420	1	Faston (Flex)	
6	3745530	4	Grommet	
7	2653210	2	Screw	
8	3654040	1	Spring Mod.Piston Ass.Y Ř 42	
9	3660430/1	2	Clutch Unit Mod.Piston Ass.Y Ř 42	
10	2321230	2	Washer	
11	2135060	2	Screw	
12	2321150	2	Washer	
13	3211015	1	Elettronic Coil	
14	3211080	1	Spark Plug Cable	
15	3782040	1	Wire Jaket	
16	3211415	1	Earth Cable	
17	4251480/1	1	Flywheel Ass.Y (Incl. 7,9,10)	
18	2670120	2	Nut	
19	2135050	3	Screw	
20	3121070	2	Seal Ring	
21	3745130	1	Grommet	
22	8521010	1	Cranckase Ass.Y	
23	3151010	1	Flywheel Key	
25	3116100	1	Needle Bearing	
27	8250840	1	Crankshaft (Incl. 25)	
28	3112240	2	Bearing	
29	3750280	1	Massathread Guide	
30	3724050	1	Gasket	
31	2432040	5	Nut	
32	2123100	3	Screw	
33	3654050	2	Spring	
34	3749570	2	Starter Hook	
35	8540810	1	Starter Cup Ass.Y (Incl.32-34)	
36	2135180	1	Screw	
37	4563663	1	Cylinder Cover Ass.Y Red	
38	4122120	1	Muffler	
41	3724340	1	Muffler Gasket	
42	3744850	1	Spark Plug Cover	
43	3657530	1	Spark Plug Spring	
44	3210024	1	Spark Plug	
45	2135150	2	Screw	
46	3724260	1	Cylinder Gasket	
47	3123150	1	Piston Ring X Mod. Ř 38	
48	3158260	1	Piston Pin	
49	3356050	2	Circlip	
50	8541120	1	Piston Ass.Y Ř 38 (Incl.26,47-49)	
51	8541110	1	Cylinder-Piston Ass.Y Ř 38 (Incl.50)	
52	4253290	1	Intake Filter	
53	8745541	1	Grommet Ass.Y	
54	8741370	1	Fuel Cap Ass.Y	
55	4252470	1	Fuel Tank Ass.Y (Incl.52-54)	
56	4122180	1	Flange (Flex)	
57	2330020	2	Grower	
58	2135010	2	Screw	
59	2330060	2	Washer	
60	2412180	1	Nut (Flex)	
61	2112310	2	Screw	
62	8724340	1	Gasket Set (Incl.30,41,46)	
63	4612587	1	Flange	

Engine 2


Pos.	Part no.	Q.ty	Description	Remarks
1	3724360	1	Intake Manif-Gasket	
2	3750410	1	Intake Manifold	
3	2670280	2	Nut	
4	2135050	2	Screw	
5	3724400	2	Intake-Carb Gasket	
6	3785070	1	Heat Block	
7	4353270/1	1	Carburettor	
8	8750390	1	Air Filter Holder	
9	2312090	3	Washer	
10	2135250	2	Screw	
11	3781600	1	Air Filter	
12	4563673	1	Filter Cover Red	
13	2123100	3	Screw	
14	3613420	1	Washer	
15	4562220	1	Starter Pulley	
16	3723640	1	Disc	
17	4611480	1	Spring	
18	8563650	1	Starter Recoil Case	
19	2135040	12	Screw	
20	3784030	1	Starter Cord	
21	3750067	1	Starter Handle	
22	3745530	4	Grommet	
23	4252680	1	Starter Ass.Y (Incl. 13-22)	
24	3744870	1	Primer	
25	4353150	1	Gasket-Diaph. Set	
30	2461030	2	Nut	

Handle-transmission






XB41 - Model Year 2008


Handle-transmission

Pos.	Part no.	Q.ty	Description	Remarks
1	2123030	4	Screw	
2	3750330	1	Front Housing Support	
3	3744290	1	Front Shock Absorber	
4	4563560	1	Front Handle	
5	2312150	2	Washer	
6	2123140	2	Screw	
7	3750340	1	Front Step-Down Spacer	
8	4563531	1	Transmission Housing	
9	8563540	1	Handgrip Housing Couple	
10	3743630	1	Safety Lever	
11	3654490	1	Spring	
12	3743620	1	Throttle Lever	
13	3749270	1	Stop Knob	
14	3612710	1	Stop Plate	
15	2123070	1	Screw	
16	3786200/1	1	Wire Sheath	
17	4252450	1	Wire Ass.Y	
18	3211120	1	Earth Cable (Black)	
19	3211490	1	Coil-Switch Cable (Red)	
20	3744300	1	Rear Shock Absorber	
21	2135150	1	Screw	
22	2432030	1	Nut	
23	2135160	4	Screw	
24	2126050	1	Screw	
25	3112170	1	Bearing	
26	3353080	1	Seeger Ring	
27	3L8520990/3	1	Transmission Hub Ass.Y	
28	4121861/1	1	Clutch	
29	3642191	1	Bearing Hub	
30	4251400	1	Transmission Shaft	
31	4251204	1	Transmission Pipe Ass.Y	
32	2312150	2	Washer	
33	2135060	2	Screw	
34	2135030	1	Screw	
35	3615000	1	Line Cutter	
36	2432040	1	Nut	
37	2312150	1	Washer	
38	8563570	1	Safety Cover Ass.Y	
39	4253460	1	Harness	

Gear case


Pos.	Part no.	Q.ty	Description	Remarks
1	4252780/1	1	Gear Case Assy	
1	4252790/1	1	Gear Case Assy R28Mm	
7	2135050	2	Screw	
8	2653090	1	Screw	
9	2653460	1	Screw	
15	3121170	1	Oil Seal	
16	3641700/1	1	Collar	
17	3641640	1	Upper Ring Nut	
18	3612640	1	Lower Ring Nut	
19	4560610	1	Stabilizer	
20	2321230	1	Washer	
21	2653170	1	Screw	
22	4611880	1	4 Teeth Disc 25 Cm	
31	4353240/1	1	2 Hedges Nylon Head	


"All Cutting" tool



Pos.	Part no.	Q.ty	Description	Remarks
------	----------	------	-------------	---------

1	6910520	1	Blade Ass.Y	
2	6910521	1	Transmission Shaft Ass.Y	
3	6910524	1	Gear Case Ass.Y	
4	6910523	1	Lever+Regulation Rod	
5	4252640	1	Coupling	
6	2382430	1	Spacer	

Pruner tool



Pos.	Part no.	Q.ty	Description	Remarks
1	6910500	1	Transmission Case Ass.Y R24	
1	6910501	1	Transmission Case Ass.Y R26	
2	6910502	1	Chain Housing	
3	6910503	1	Oil Tank	
4	6910504	1	Cover R24	
4	6910505	1	Cover R26	
5	6910506	1	Flange	
6	6910507	1	Screw	
7	6910508	1	Oil Pump Ass.Y	
8	4112610	1	Guide Bar 10"	10" 3/8" .042" (1.1 mm)
9	4113551	1	Chain 10"	10" 3/8" .042" (1.1 Mm) - 38E